



Technical Data Sheet

Zircadyne® Zirconium Corrosion Data

THE FOLLOWING TABLES OUTLINE ALL ZIRCONIUM PRODUCT CORROSION DATA IN ALPHABETICAL ORDER.

TABLE 1

Corrosive Media	Concentratio n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Acetaldehyde	100	Boiling	<2	-	
Acetic Acid	5-99.5	35-Boiling	<1	<1	
Acetic Acid (anhydride)	99	Room-Boiling	<1	<1	
Acetic Acid (glacial)	99.7	Boiling	<5	-	
Acetic Acid	100	200	<1	<1	
Acetic Acid + 1% Acetyl Chloride	99	Boiling	>50	-	
Acetic Acid (glacial) + 0.5% CH ₃ OH	99	200	<1	-	
Acetic Acid (glacial) + 200 ppm FeCl ₃	99	200	<1	-	
Acetic Acid (glacial) + 0.5% CH ₃ OH + 200 ppm FeCl ₃ + 1% H ₂ O	98	200	<1	-	
Acetic Acid + 50 ppm I ⁻ (KI)	100	160, 200	<1	-	
Acetic Acid + 1% I ⁻ (KI) + 100 ppm Fe ⁺³ (Fe ₂ (SO ₄) ₃)	99	200	<1	<1	
Acetic Acid + 2% HI	80	100	<1	<1	
Acetic Acid + 2% HI + 1000 ppm Fe (Fe powder)	80	100	<1	-	
Acetic Acid + 2% HI + 1% methanol + 500 ppm formic + 100 ppm Cu	80	150	<1	<1	
Acetic Acid + 2% HI + 1% methanol + 500 ppm formic + 100 ppm Fe	80	150	<1	<1	
Acetic Acid + 2% HI	98	150	<1	<1	

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
 Data on any particular piece of material may vary from those herein.
 U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
 1000 Six PPG Place
 Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com

Zircadyne® Zirconium Corrosion Data



Technical Data Sheet

Acetic Acid + 2% HI + 200 ppm Fe ⁺³ (FeCl ₃)	80	100	<1	<1	
Acetic Acid + 2% HI + 200 ppm Fe ⁺³ (Fe ₂ (SO ₄) ₃)	80	100	<1	<1	
Acetic Acid + 2% I ⁻ (KI)	98	100	<1	<1	

TABLE 2

Corrosive Media	Concentration %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Acetic Acid +2% HI + 1% CH ₃ OH = 500 ppm HCOOH	80	150	<1	<1	
Acetic Acid + 2% HI +200 ppm Cl ⁻ (NaCl)	80	100	<1	<1	
Acetic Acid + 50% Acetic Anhydride	50	Boiling	<1	<1	
Acetic Acid + 50% 48% HBr	50	115	<1	<1	
Acetic Acid + Saturated gaseous HCl and Cl ₂	100	Boiling	>200	>200	
	100	40	<1	-	
Acetic Acid + 0.5% CH ₃ OH + 200 ppm FeCl ₃ + 5% H ₂ O	94	200	<1	-	
Acetic Acid + 10% CH ₃ OH	90	200	<1	-	
Acetic Acid + 10% CH ₃ OH + 200 ppm FeCl ₃ + 5% H ₂ O	84	200	<1	-	
Acetic Acid + 10% CH ₃ OH + 200 ppm FeCl ₃ + 1% H ₂ O	88	200	<1	-	
Acetyl Chloride	100	25	>200	-	
Aluminum Chlorate	30	100	<2	-	
Aluminum Chloride	5, 10, 25	35-100	<1	-	
	25	Boiling	<1	<1	
	40	100	<2	-	
Aluminum Chloride (aerated)	5, 10	60	<2	-	
Aluminum Chloride	25-50	Boiling	<1	<1	
Aluminum Chloride + Saturated 1% HCl	-	RT	<1	-	
	-	110	10-20	-	

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
Data on any particular piece of material may vary from those herein.
U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com

Zircadyne® Zirconium Corrosion Data



Technical Data Sheet

Aluminum Fluoride	20	Room	>50	-	pH = 3.2
Aluminum Fluoride + 0.5% HF + 16% Zr sponge	7.2	90	<1	-	
Aluminum Potassium Sulfate	10	Boiling	nil	nil	pH = 3.2

TABLE 3

Corrosive Media	Concentratio n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Aluminum Sulfate	25	Boiling	nil	nil	
	60	100	<2	-	
Ammonia (wet)	+ water	38	<5	-	
Ammonium Carbamate	-	193	<1	-	58.4% Urea, 16.8% Ammonia, 14.8% CO ₂ , 9.9% H ₂ O at 3,200-3,500 psi
Ammonium Chloride	1, 10, saturated	35-100	<1	-	
Ammonium Hydrogen Phosphate	22.8	204	nil	-	
Ammonium Hydroxide	28	Room-100	<1	-	
Ammonium Fluoride	20	28	>50	-	pH = 8
	20	98	>50	-	pH = 8
Ammonium Oxalate	100	100	<2	-	
Ammonium Sulfate	10	Boiling	nil	-	
Aniline Hydrochloride	5.20	35-100	<1	-	
	5.20	100	<2	-	
Aqua Regia	3.1	Room	>50	-	3 parts HCl, 1 part HNO ₃
Barium Chloride	5, 20	35-100	<1	-	
	25	Boiling	5-10	-	
Bromine	100-Liquid	20	<10	20-50	Pitting
	Vapor	20	-	>50	Pitting
Bromochloromethane	100	100	<2	-	
Cadmium Chloride	100	Room	<2	-	
Calcium Bromide	100	100	<2	-	
Calcium Chloride	5, 10, 25	35-100	<1	-	
	70	Boiling	<1	<1	B.P. = 162°C

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
Data on any particular piece of material may vary from those herein.
U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com

Zircadyne® Zirconium Corrosion Data



Technical Data Sheet

	75	Boiling	<5	-	
Mixture		79	<1	-	14% CaCl ₂ , 8% NaCl, 0.2% Ca(OH) ₂

TABLE 4

Corrosive Media	Concentration n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Calcium Chloride + 0.1% MgCl ₂	0.2	80	<1	-	pH = 1
Calcium Chloride + 0.1% MgCl ₂ + 300 ppm F ⁻ (as CaF ₂)	0.2	80	>50	-	pH = 1
Calcium Chloride + 0.1% MgCl ₂ + 300 ppm F ⁻ (as CaF ₂) + 1200 ppm P ₂ O ₅	0.2	80	5-20	-	pH = 1
Calcium Chloride + 1% MgCl ₂	2	80	<1	-	pH = 1
Calcium Chloride + 1% MgCl ₂ + 300 ppm F ⁻ (as CaF ₂)	2	80	>50	-	pH = 1
Calcium Chloride + 1% MgCl ₂ + 300 ppm F ⁻ (as CaF ₂) + 1200 ppm P ₂ O ₅	2	80	<1	-	pH = 1
Calcium Chloride + 3.3% MgCl ₂	6.6	80	<1	-	pH = 1
Calcium Chloride + 3.3% MgCl ₂ + 300 ppm F ⁻ (as CaF ₂)	6.6	80	20-25	-	pH = 1
Calcium Chloride + 3.3% MgCl ₂ + 300 ppm F ⁻ (as CaF ₂) + 1200 ppm P ₂ O ₅	6.6	80	<1	-	pH = 1
Calcium Fluoride	Saturated	28	nil	-	pH = 5
	Saturated	90	nil	-	pH = 5
Calcium Hypochlorite	2, 6, 20	100	<5	-	
Carbonic Acid	Saturated	100	<5	-	
Carbon Tetrachloride	0-100	Room-100	<2	-	
Chlorine (water saturated)	-	Room	>50	-	
	-	75	>50	-	
Chlorine Gas (more than 0.13% H ₂ O)	100	94	>50	-	
Chlorine Gas (dry)	100	Room	<5	-	

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
Data on any particular piece of material may vary from those herein.
U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com

Zircadyne® Zirconium Corrosion Data



Technical Data Sheet

Chlorinated Water	-	100	<2	-	
-------------------	---	-----	----	---	--

TABLE 5

Corrosive Media	Concentration n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Chloroacetic Acid	100	Boiling	<1	-	
Chlorosulfonic Acid	100	R.T.	5-10	-	
	100	0	<2	-	
Chromic Acid	10-50	Boiling	<1	-	
Citric Acid	10-50	35-100	<1	-	
	10, 25, 50	100	<1	-	
	50	Boiling	<5	-	
Chrome Plating Solution	-	66	>50	>50	M + T Chemicals CR-100
Cupric Chloride	5, 10, 20	35-100	>50	>50	
	20, 40, 50	Boiling	>50	>50	
Cupric Cyanide	Saturated	Room	>50	-	
Cupric Nitrate	40	Boiling	nil	nil	B.P. = 115°C
Dichloroacetic Acid	100	Boiling	<20	-	
Ethylene Dichloride	100	Boiling	<5	-	
Ferric Chloride	0-50	Room-100	>50	>50	
	0-50	Boiling	>50	>50	
Ferric Sulfate	10	0-100	<2	-	
Formaldehyde	6-37	Boiling	<1	<1	
	0-70	Room-100	<2	-	
Fluoboric Acid	5-20	Elevated	>50	-	
Fluosilicic Acid	10	Room	>50	-	
Formic Acid	10-90	35-Boiling	<1	-	
Formic Acid (aerated)	10-90	Room-100	<1	-	
Formic Acid	50	Boiling	<1	<1	
	70, 98	Boiling	<1	-	
Formic Acid + 5% H ₂ SO ₄	50, 70, 93	Boiling	<1	-	
Formic Acid + 5% HCl	50, 70, 85	Boiling	<1	-	
Formic Acid + 1% Fe Powder	50, 70, 98	Boiling	<1	-	

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
Data on any particular piece of material may vary from those herein.
U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com

Zircadyne® Zirconium Corrosion Data



Technical Data Sheet

TABLE 6

Corrosive Media	Concentration n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Formic Acid + 1% Cu ⁺²	50, 70, 96	Boiling	<1	-	
Formic Acid + 5% HI	50, 70, 90	Boiling	<1	-	
Hydrazine	50	200	nil	nil	
	Mixture	109	<1	-	2% Hydrazine + saturated NaCl + 6% NaOH
	Mixture	130	nil	-	2% Hydrazine + saturated NaCl + 6% NaOH
Hydriodic Acid	47	120	<1	<1	
Hydrobromic Acid	48	Boiling	<5	<5	B.P. + 125°C (shallow pits) 24% HBr + 50% Acetic Acid (glacial)
	Mixture	Boiling	<1	<1	B.P. + 125°C (shallow pits) 24% HBr + 50% Acetic Acid (glacial)
Hydrochloric Acid	2	100	<1	-	
	2	225	<1	<1	
	10	30	<1	-	
	10	100	<1	-	
	20	30	<1	-	
	20	100	<1	-	
	20	150	<2	-	
	32	30	<1	-	
	32	77	<1	-	Weld sensitization
	37	30	<1	-	Weld sensitization
	37	51	<2	-	Weld sensitization
Hydrochloric Acid + Cl ₂ gas	20	58	5-10	-	Pitting
	37	58	<5	-	
Hydrochloric Acid + 100 ppm FeCl ₃	10	30	<1	<1	SCC observed

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
 Data on any particular piece of material may vary from those herein.
 U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
 1000 Six PPG Place
 Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com

Zircadyne® Zirconium Corrosion Data



Technical Data Sheet

TABLE 7

Corrosive Media	Concentration n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Hydrochloric Acid + 100 ppm FeCl ₃	20	105	<5	-	
	34	53	5-10	-	SCC observed
Hydrochloric Acid + 50 ppm Fe ⁺³	10	30	<1	-	
	10	60	<1	-	
	10	100	<1	-	Pitting
	20	30	<1	-	
	20	60	<1	-	
	20	100	<1	-	Pitting
	32	30	<1	-	
	32	77	<2	-	Weld sensitization
	37	30	<2	-	Weld sensitization
	37	51	<5	-	Weld sensitization
Hydrochloric Acid + 100 ppm Fe ⁺³	10	30	<1	-	
	10	60	<1	-	
	10	100	<1	-	Pitting
	20	30	<1	-	
	20	60	<1	-	Pitting
	20	100	<1	-	
	32	30	<1	-	
	32	77	<2	-	Weld sensitization
	37	30	<2	-	Weld sensitization
	37	51	<5	-	Weld sensitization
Hydrochloric Acid + 500 ppm Fe ⁺³	10	30	<1	-	Pitting, SCC
	10	60	<1	-	Pitting, SCC
	10	100	<1	-	Pitting, SCC
	20	30	<1	-	Pitting, SCC
	20	60	<1	-	Pitting, SCC
	20	100	<1	-	Pitting, SCC

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
Data on any particular piece of material may vary from those herein.
U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com

Zircadyne® Zirconium Corrosion Data



Technical Data Sheet

TABLE 8

Corrosive Media	Concentration n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Hydrochloric Acid + 500 ppm Fe ⁺³	32	30	<1	-	SCC
	32	77	<5	-	Weld sensitization, SCC
	37	30	<2	-	Weld sensitization, SCC
	37	51	<5	-	Weld sensitization, SCC
Hydrochloric Acid + 200 ppm HF	10	100	>50	-	
Hydrochloric Acid + 200 ppm HF + 800 ppm Zr sponge	10	100	<1	-	
Hydrochloric Acid	Mixture	Room	Dissolved	-	20% HCl + 20% HNO ₃
	Mixture	Room	Dissolved	-	10% HCl + 10% HNO ₃
Hydrofluoric Acid	All	Room	>50	-	
Hydrogen Peroxide	30	Boiling	nil	nil	
	50	100	<2	-	
Hydroxyacetic Acid	70	205	<1	<1	
Iodine Vapor	-	100, 180	<1	-	
Iodine Liquid	100	120	5-20	-	
	100	180	>50	-	
Lactic Acid	10-100	148	<1	-	
	10-85	35-Boiling	<1	-	
Lithium Chloride	Saturated	30-80	5-10	-	
Lithium Chloride	Saturated	80	nil	-	pH adjusted to 6.0 with NaOH
Magnesium Chloride	5-40	Room-100	<2	-	
	47	Boiling	nil	nil	
	30	Boiling	<2	<2	
Magnesium Chloride + 1% HCl	30	Boiling	<2	<2	
Magnesium Chloride + 5% HCl	30	Boiling	<2	<2	
Magnesium Chloride + 10% HCl	30	Boiling	<2	<2	

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
Data on any particular piece of material may vary from those herein.
U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com

Zircadyne® Zirconium Corrosion Data



Technical Data Sheet

TABLE 9

Corrosive Media	Concentration %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Manganese Chloride	5, 20	Room-100	<1	-	
Mercuric Chloride	Saturated	35-100	<1	-	
	Saturated	Boiling	<1	<1	
Methanol	100	Boiling 200	nil	nil	
Methanol + 0.1% KI + 0.1% HCOOH	99.8	65	nil	nil	
Methanol + 1% KI	99	200	<1	<1	500 ppm Fe ⁺³
Nickel Chloride	5, 20	35-100	<1	-	
	5-20	100	<1	-	
	30	Boiling	nil	nil	
Nitric Acid	20	103	<1	<1	
	70	121	<1	<1	
	10-70	Room-260	<1	-	
	70-98	Room-Boiling	<1*	-	*SCC observed
	80	120, 150	<1	-	
	90	120, 150	<1	-	
Nitric Acid + Saturated Cl ₂	30, 50, 70	Boiling	<1	-	Pitting may be observed in the vapor phase
Nitric Acid + 200 ppm HF	90	25	>50	-	
Nitric Acid + 200 ppm HF + 800 ppm Zr sponge	90	25	<1	-	
Nitric Acid + 1% Fe	65	120, 204	<1	-	
Nitric Acid + 1.45% 304 S.S.	65	120, 204	nil	-	
Nitric Acid + 1% Cl ⁻ (as NaCl)	30, 50, 70	120	nil	-	
Nitric Acid + 1% Seawater	70	120	nil	-	
Nitric Acid + 1% FeCl ₃	70	120	nil	-	
Oxalic Acid	0-100	100	<1	-	

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
Data on any particular piece of material may vary from those herein.
U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com

Zircadyne® Zirconium Corrosion Data



Technical Data Sheet

TABLE 10

Corrosive Media	Concentration n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Perchloric Acid	70	100	<2	-	
Phenol	Saturated	Room	<5	-	
Phosphoric Acid	5-30	Room	<5	-	
	5-35	60	<5	-	
	5-50	100	<5	-	
	35-50	Room	<5	-	
	45	Boiling	<5	-	
	50	Boiling	<5	10-15	B.P. = 108°C
	65	100	5-10	<20	
	70	Boiling	>50	>50	B.P. = 123-126°C
	85	38	5-20	-	
	85	80	20-50	20-50	
	85	Boiling	>50	>50	B.P. = 156°C
	Mixture	Room	nil	-	88% H ₃ PO ₄ + 0.5% HNO ₃
	Mixture	Room	nil	-	88% H ₃ PO ₄ + 5% HNO ₃
	Mixture	89	>50	>50	85% H ₃ PO ₄ + 4% HNO ₃
	20	150	<1	-	
Phosphoric Acid + 4.3% Ammonia	18	204	nil	-	
Phosphoric Acid + 2 ppm F ⁻	30-50	Boiling	20-50	-	
Phosphoric Acid + 4.3% NH ₃	18.5	204	<1	-	
Potassium Chloride	Saturated	60	<1	-	
	Saturated	Room	<1	-	
Potassium Fluoride	20	28	nil	-	pH = 8.9
	20	90	>50	-	pH = 8.9
	0.3	Boiling	<1	-	

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
Data on any particular piece of material may vary from those herein.
U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com

Zircadyne® Zirconium Corrosion Data



Technical Data Sheet

TABLE 11

Corrosive Media	Concentratio n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Potassium Hydroxide	50	27	<1	-	
	10	Boiling	<1	-	
	25	Boiling	<1	-	
	50	Boiling	<1	-	
	50-anhydrous	241-377	>50	-	
	Mixture	29	<1	-	13% KOH, 13% KCl
Potassium Iodide	0-70	Room-100	<2	<2	
Potassium Nitrite	0-100	Room-100	<2	-	
Silver Nitrate	50	Room	<5	-	
Sodium Bisulfate	40	Boiling	<1	<1	B.P. = 107°C
Sodium Carbonate	10	R.T.-Boiling	<1	<1	
Sodium Chlorate	20	Boiling	nil	-	
Sodium Chloride	3-Saturated	35-Boiling	<1	<1	
	29	Boiling	<1	-	
	Saturated	Room	<1	-	
	Saturated	Boiling	<1	<1	Adjusted to pH = 1
	Saturated	107	nil	-	Adjusted to pH = 0
Sodium Chloride + Saturated SO ₂	3.5	80	nil	-	
	25	80	nil	-	
	Saturated	80	nil	-	
Sodium Chloride	Mixture	215	nil	nil	25% NaCl + 0.5% Acetic Acid + 1% S + Saturated H ₂ S
Sodium Chloride + 0.5% CH ₃ COOH + Saturated H ₂ S	25	R.T.-Boiling	<1	<1	
Sodium Chloride + 0.5% CH ₃ COOH + 0.1% S + Saturated (H ₂ S + CO ₂)	25	204, 232	<1	-	
Sodium Chloride + 0.5% CH ₃ COOH + 0.1% S + Saturated H ₂ S	25	250	<1	<1	

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
Data on any particular piece of material may vary from those herein.
U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com

Zircadyne® Zirconium Corrosion Data



Technical Data Sheet

TABLE 12

Corrosive Media	Concentratio n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Sodium Fluoride	Saturated	28	nil	-	
	Saturated	90	>50	-	
Sodium Formate	0-80	100	<2	-	
Sodium Hydrogen Sulfite	40	Boiling	<1	<1	
Sodium Hydroxide	5-10	21	<1	-	
	28	Room	<1	-	
	10-25	Boiling	<1	-	
	40	100	<1	-	
	50	38-57	<1	-	
	50	149	<2	<2	
	50-73	188	20-50	-	
	70	150	<5	-	
	73	110-129	<2	-	
	73 to anhydrous	212-538	20-50	-	
	Mixture	82	<1	-	9-11% NaOH, 15% NaCl
	Mixture	10-32	<1	-	10% NaOH, 10% NaCl & wet CoCl_2
	Mixture	129	<1	-	0.6% NaOH, 2% NaClO_3 + trace of NH_3
	Mixture	191	<1	-	7% NaOH, 53% NaCl, 7% NaClO_3 , 80-100 ppm NH_3
	Mixture	138	<5	-	52% NaOH + 16% NH_3
Sodium Hydroxide (Suspended salt-violent boiling)	20	60	10-20	-	
Sodium Hydroxide + 750 ppm Free Cl_2	50	38	<1	-	
	50	38-57	<1	-	

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
 Data on any particular piece of material may vary from those herein.
 U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
 1000 Six PPG Place
 Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com



Zircadyne® Zirconium Corrosion Data

Technical Data Sheet

TABLE 13

Corrosive Media	Concentratio n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Sodium Hypochlorite	6	100	<5	-	as received super chlor.
	6	50	nil	nil	
Sodium Iodide	0-60	100	<2	-	
Sodium Peroxide	0-100	Room-100	<2	-	
Sodium Oxychloride +15% Sodium Chloride + 5% Sodium Carbonate	15	46	0	<1	
Sodium Silicate	0-100	Room-100	<2	-	
Sodium Sulfate	0-20	Room-100	<2	-	
Sodium Sulfide	10	200	nil	nil	
	33	Boiling	nil	nil	
Stannic Chloride	5	100	<1	-	
	24	Boiling	<1	-	
Succinic Acid	0-50	100	<2	-	
	100	150	<2	-	
Sulfuric Acid	0-75	20	<1	<1	
	80	20	<5	-	
	80	30	20-50	>50	
	77.5	60	10-20	<10	
	75	50	<1	-	
	77	50	5-10	-	
	80	50	>50	>50	
	75	80	<5	<5	
	65	100	-	<5	
	70	100	<2	<5	
	75	100	<5	<5	
	76	100	<10	-	
	77	100	<20	-	
	77.5	100	>50	>50	

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
Data on any particular piece of material may vary from those herein.
U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com

Zircadyne® Zirconium Corrosion Data



Technical Data Sheet

TABLE 14

Corrosive Media	Concentration %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Sulfuric Acid	60	130	–	<5	
	65	130	<1	–	
	70	140	<5	<10	
	58	Boiling	–	<5	B.P. = 140°C
	62	Boiling	<5	10-20	B.P. = 146°C
	64	Boiling	<5	20-50	B.P. = 152°C
	68	Boiling	<5	–	B.P. = 165°C
	69	Boiling	<5	–	B.P. = 167°C
	71	Boiling	<5	–	B.P. = 171°C
	72-74	Boiling	5-10	–	
	75	Boiling	10-20	–	B.P. = 189°C
Sulfuric Acid + 1,000 ppm Fe ³⁺	60	Boiling	<1	–	B.P. = 142°C
Sulfuric Acid + 10,000 ppm Fe ³⁺	60	Boiling	<5	–	Added as Fe ₂ (SO ₄) ₃
Sulfuric Acid + 200-1,000 ppm Fe ³⁺	65	Boiling	<5	–	B.P. = 152-155°C
Sulfuric Acid + 10,000 ppm Fe ³⁺	65	Boiling	5-10	–	Added as Fe ₂ (SO ₄) ₃
Sulfuric Acid + 14 ppm-141 ppm Fe ³⁺	70	Boiling	5-10	–	B.P. = 167-171°C
Sulfuric Acid + 200 ppm	70	Boiling	10-20	–	Added as Fe ₂ (SO ₄) ₃
Sulfuric Acid + 1,410 ppm-10,000 ppm Fe ³⁺	70	Boiling	>50	–	
Sulfuric Acid + 1,000 ppm FeCl ₃	60	Boiling	<5	<20	B.P. = 138-142°C
Sulfuric Acid + 10,000 ppm FeCl ₃	60	Boiling	<5	20-50	
Sulfuric Acid + 20,000 ppm FeCl ₃	60	Boiling	20-50	>50	

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
 Data on any particular piece of material may vary from those herein.
 U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
 1000 Six PPG Place
 Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com



Zircadyne® Zirconium Corrosion Data

Technical Data Sheet

TABLE 15

Corrosive Media	Concentration n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Sulfuric Acid + 200 ppm FeCl ₃	65	Boiling	<5	<20	B.P. = 152-155°C
Sulfuric Acid + 1,000 ppm FeCl ₃	65	Boiling	<5	<20	
Sulfuric Acid + 10,000 ppm FeCl ₃	65	Boiling	<5	<20	
Sulfuric Acid + 10 ppm FeCl ₃	70	Boiling	<20	>50	B.P. = 167-171°C
Sulfuric Acid + 100 ppm FeCl ₃	70	Boiling	<20	>50	
Sulfuric Acid + 200 ppm FeCl ₃	70	Boiling	<20	>50	
Sulfuric Acid + 1,000 ppm FeCl ₃	70	Boiling	<20	>50	
Sulfuric Acid + 10,000 ppm FeCl ₃	70	Boiling	20-50	>50	
Sulfuric Acid + 200 ppm Cu ²⁺	60	Boiling	<5	-	Added as CuSO ₄
Sulfuric Acid + 1,000-10,000 ppm Cu ²⁺	60	Boiling	<1	-	
Sulfuric Acid + 200-10,000 ppm Cu ²⁺	65	Boiling	<5	-	Added as CuSO ₄
Sulfuric Acid + 3 ppm Cu ²⁺	70	Boiling	5-10	-	Added as CuSO ₄
Sulfuric Acid + 27-266 ppm Cu ²⁺	70	Boiling	>50	-	
Sulfuric Acid + 1,000-10,000 ppm NO ₃ ⁻	60	Boiling	<5	-	Added as NaNO ₃
Sulfuric Acid + 50,000 ppm NO ₃ ⁻	60	Boiling	>50	-	

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
Data on any particular piece of material may vary from those herein.
U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com

Zircadyne® Zirconium Corrosion Data



Technical Data Sheet

TABLE 16

Corrosive Media	Concentratio n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Sulfuric Acid + 200-1,000 ppm NO ₃ ⁻	65	Boiling	<5	—	Added as NaNO ₃
Sulfuric Acid + 10,000 ppm NO ₃ ⁻	65	Boiling	10-20	—	
Sulfuric Acid + 50,000 ppm NO ₃ ⁻	65	Boiling	>50	—	
Sulfuric Acid + 200 ppm NO ₃ ⁻	70	Boiling	5-10	—	Added as NaNO ₃
Sulfuric Acid + 6,000 ppm NO ₃ ⁻	70	Boiling	20-50	—	
Sulfuric Acid + 1,000 ppm NO ₃ ⁻	60	Boiling	<5	—	Added as HNO ₃
Sulfuric Acid + 10,000 ppm NO ₃ ⁻	60	Boiling	10-20	—	
Sulfuric Acid + 50,000 ppm NO ₃ ⁻	60	Boiling	>50	—	
Sulfuric Acid + 1,000 ppm NO ₃ ⁻	65	Boiling	<5	—	Added as HNO ₃
Sulfuric Acid + 10,000-50,000 ppm NO ₃ ⁻	65	Boiling	>50	—	
Sulfuric Acid	Mixture	Room-100	<1	—	1% H ₂ SO ₄ , 99% HNO ₃
	Mixture	Room-100	nil	—	10% H ₂ SO ₄ , 90% HNO ₃
	Mixture	Boiling	<1	—	14% H ₂ SO ₄ , 14% HNO ₃
	Mixture	100	>50	>50	25% H ₂ SO ₄ , 75% HNO ₃
	Mixture	Room	<1	—	50% H ₂ SO ₄ , 50% HNO ₃
	Mixture	Boiling	>50	>50	68% H ₂ SO ₄ , 5% HNO ₃
	Mixture	Boiling-135	10-20	>50	68% H ₂ SO ₄ , 1% HNO ₃
	Mixture	Room	>50	>50	75% H ₂ SO ₄ , 20% HNO ₃

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
Data on any particular piece of material may vary from those herein.
U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com



Zircadyne® Zirconium Corrosion Data

Technical Data Sheet

TABLE 17

Corrosive Media	Concentration n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Sulfuric	Mixture	Boiling	<1	-	7.5% H ₂ SO ₄ , 19% HCl
	Mixture	Boiling	<1	-	34% H ₂ SO ₄ , 17% HCl
	Mixture	Boiling	<1	-	40% H ₂ SO ₄ , 14% HCl
	Mixture	Boiling	1-5	-	56% H ₂ SO ₄ , 10% HCl
	Mixture	Boiling	<1	-	60% H ₂ SO ₄ , 1.5% HCl
	Mixture	Boiling	<5	-	69% H ₂ SO ₄ , 1.5% HCl
	Mixture	Boiling	10-20	-	69% H ₂ SO ₄ , 4% HCl
	Mixture	Boiling	<20	-	72% H ₂ SO ₄ , 1.5% HCl
	Mixture	Boiling	>50	>50	20% H ₂ SO ₄ , 7% HCl with 50 ppm F impurities
	2	225	<1	<1	
	5	232	<1	<1	
	10	225	<1	-	
	15	225	<5	-	
Sulfuric Acid + 11% SnSO ₄	10	103	<1	<1	
Sulfuric Acid + 1% SnSO ₄	35	103	<1	<1	
Sulfuric Acid + 8% Fe	20	80	<1	-	
Sulfurous Acid	6	Room	<5	-	
	Saturated	192	5-50	-	
Sulfamic Acid	10	Boiling	nil	nil	B.P. = 101°C
Tannic Acid	25	35-100	<1	-	
Tartaric Acid	10-50	35-100	<1	-	
Trichloroacetic Acid	10-40	Room	<2	-	
	100	Boiling	>50	-	
	100	100	>50	-	B.P. = 195°C
Tetrachloroethane	100	Boiling	<5	-	B.P. = 146°C symmetrical B.P. = 129°C unsymmetrical
Trichloroethylene	99	Boiling	<5	-	B.P. = 87°C

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
Data on any particular piece of material may vary from those herein.
U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com

Zircadyne® Zirconium Corrosion Data



Technical Data Sheet

TABLE 18

Corrosive Media	Concentratio n %	Temperature °C	CORROSION RATE, mpy		Remarks
			Zr 702	Zr 705	
Trisodium Phosphate	5-20	100	<5	–	
Urea	50	Boiling	0.1	0.1	
Urea Reactor Mixture	Mixture	193	<1	–	58 Urea, 17 NH ₃ , 15 CO ₂ , 10 H ₂ O
Water - Sea (Pacific)	–	Boiling	nil	nil	
	–	200	nil	–	pH = 7.6
White Liquor	–	121, 177, 227	<1	<1	A mixture of NaOH, Na ₂ S, Na ₂ CO ₃ , etc.
Zinc Chloride	70	Boiling	nil	nil	
	5-20	35-Boiling	<1	–	
	40	Boiling-180	<1	<1	

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
 Data on any particular piece of material may vary from those herein.
 U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
 1000 Six PPG Place
 Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com